

## **EZ-Tap Pro Quick-Start Guide**

### **Device Driver Installation**

Please visit <http://www.stratusengineering.com/Downloads.html> to download the latest copy of this file and the EZ-Tap/EZ-Tap Pro device drivers and installation guide for your operating system. Note that EZ-Tap and EZ-Tap Pro use the same device driver. The typical user will unzip the driver files into a directory on his/her hard drive and use the Windows hardware installation wizard to complete the installation. If this does not work for you, refer to the instructions in the appropriate driver installation guide for help. Once the EZ-Tap/EZ-Tap Pro driver has been correctly installed, EZ-Tap Pro will be shown as a USB COM port under Windows Device Manager.

### **EZ-View RS232 Monitor Application**

Stratus Engineering's EZ-View RS232 Monitor program Version 1.3.0.1 or higher is currently the only application program available for use with EZ-Tap Pro. EZ-View now works with EZ-Tap Pro as well as EZ-Tap and offers the same user interface for both devices. The only difference between the two devices from the EZ-View user standpoint is that EZ-View provides exact microsecond time-tagging for all data and handshaking events when used with EZ-Tap Pro. You can download the latest version of EZ-View at <http://www.stratusengineering.com/Downloads.html>.

### **EZ-Tap Pro Firmware update**

Your EZ-Tap Pro shipped with firmware version 24 and does not require an update. This version has been stable for about 2 years and we do not anticipate further updates. You can confirm the firmware version from the "EZ-View Help\About" menu.

### ***Developing Custom software with the EZ-Tap Pro Software API***

Please contact Stratus Engineering for information on developing custom application software for use with the EZ-Tap Pro hardware module